Industrial specification sheet





Remote Control

Remote control for commissioning

Accessories

No accessories required

PRODUCT CODES

	Description
HBREM	Remote control for commissioning



01604 495 151 collingwoodlighting.com

collingwoodled

f /collingwoodlighting

in collingwoodlighting

Guarantee

5 years

Features & benefits

One remote for all control options Use with sensor -HBPIR HBMWS HBDLS HBLMWS

Press 'Start' to begin, commission the sensor within the first high bay

Press 'Memory' to save those setting

Press 'Apply' to send the saved settings to the next high bay

Light will flicker when receiving settings from the remote to confirm commissioning is complete

Batteries are included